Use & Care Instructions



LOOX LIGHTING

TO PROTECT AND MAINTAIN OPTIMAL PERFORMANCE, PLEASE FOLLOW THESE GUIDELINES:

- Clean with a dry, soft, non-abrasive cloth
- Avoid the use of liquids or harsh cleaners
- De-energize all lighting and power sources before cleaning in order to avoid shock hazard.
- Periodically inspect wiring and system components for damaged or loose connections in plugs and cabling.
 "Discontinue use if damaged."

