

Display boards are supplied with two types of brackets for use on the complete range of HÄFELE towers or wall displays.

On some tower or wall displays, it will be necessary to remove the three white KEKU brackets on the back of the boards. See Illustration.

This is easily done by removing the two screws from each KEKU.

Note that the black metal brackets will remain on the board regardless of the HÄFELE tower or wall system used.

