

# **PRODUCT GUIDE**

## 18" PULL-OUT HAMPER 300.3148.[FIN]

#### DESCRIPTION & SPECIFICATIONS


Sort-as-you-go with the 18" Pull-Out Hamper. The large removable hamper bag lifts out of the frame and features comfortable hand grips so that laundry can be easily transported.

SIZE & CAPACITY | 18" w 1 Large Hamper Bag



Matte Aluminum, Polished Chrome, Matte Nickel, Oil Rubbed Bronze, Polished Brass, Matte Brass.





Mounting Locations

# INSTRUCTIONS & SPECIFICATIONSFINISHCODE (FIN)STEP 1: Press slide leveller down and remove slide rails from the hamper.MATTE ALUMINUMMALSTEP 2: Mount slide rails to partition using euro screws.POLISHED CHROMECRSTEP 3: Extend the slide on the hamper and re-install on slide rail.MATTE NICKELMNLSTEP 4: Set hamper to fully retracted position and insert the bag.OIL RUBBED BRONZEORB- Four (4) #5 Euro Screws are required to mount.MATTE BRASSMBSPOLISHED BRASSBSMATTE DICKELMATTE DICKEL

#### Storage Accessories. Differentiated by Design.

www.TAGHardware.com



# **PRODUCT GUIDE**

## 24" PULL-OUT HAMPER 300.3140.[FIN]

#### DESCRIPTION & SPECIFICATIONS


Sort-as-you-go with the 24" Pull-Out Hamper. The two small removable hamper bags lift out of the frame and feature comfortable hand grips so that laundry can be easily transported.

#### SIZE & CAPACITY | 24" w 2 Small Hamper Bags



Matte Aluminum, Polished Chrome, Matte Nickel, Oil Rubbed Bronze, Polished Brass, Matte Brass.





#### INSTRUCTIONS & SPECIFICATIONS

STEP 1: Press slide leveller down and remove slide rails from the hamper.
STEP 2: Mount slide rails to partition using euro screws.
STEP 3: Extend the slide on the hamper and re-install on slide rail.
STEP 4: Set hamper to fully retracted position and insert the bags.
Four (4) #5 Euro Screws are required to mount.

FINISHCODE (FIN)MATTE ALUMINUMMALPOLISHED CHROMECRMATTE NICKELMNLOIL RUBBED BRONZEORBMATTE BRASSMBSPOLISHED BRASSBS

#### Storage Accessories. Differentiated by Design.

www.TAGHardware.com



# **PRODUCT GUIDE**

## 30" PULL-OUT HAMPER 300.3143.[FIN]


#### DESCRIPTION & SPECIFICATIONS

Sort-as-you-go with the 30" Pull-Out Hamper. The large and small removable hamper bags lift out of the frame and feature comfortable hand grips so that laundry can be easily transported.



Matte Aluminum, Polished Chrome, Matte Nickel, Oil Rubbed Bronze, Polished Brass, Matte Brass.





# INSTRUCTIONS & SPECIFICATIONS STEP 1: Press slide leveller down and remove slide rails from the hamper. STEP 2: Mount slide rails to partition using euro screws. STEP 3: Extend the slide on the hamper and re-install on slide rail. STEP 4: Set hamper to fully retracted position and insert the bags. - Four (4) #5 Euro Screws are required to mount. Four (4) #5 Euro Screws are required to mount.

#### Storage Accessories. Differentiated by Design.

www.TAGHardware.com