

Mounting Guideline Waste Bin Pull Out

Please install set screws on both sides of the runner supports at the front and back position!

Failure to install these mounting screws could lead to twisting of the runner during operation, causing lower stability and premature wear.

