

## DTSH Door Terminal Set, Tag-it ANSI

**Note:** The DTSH is activated by a light difference in front of the upper label. This is a touchless wake up system.

### How to program DTSH units for simple mode of operation

Configure DTSH for simple programming:

- Place a white piece of paper in front of the upper label. This will wake up the unit.

### Simple programming

To create programming key tags:

- Present green key tag to the DTSH to create the programming ADD key while the green LED is flashing.
- Remove the green key tag.
- Present red key tag to the DTSH to create the programming DELETE key tag.
- Remove the red key tag.

To create user key(s):

- Present the green programming ADD key tag to the DTSH to start the add sequence.
- Remove the green tag.
- Present one or more user key tags in succession to the DTSH.
- The unit will go back to sleep after a few seconds.
- Use one of the user keys to unlock and lock the unit.

### Normal Use of DTSH in Simple Mode

- Present any authorized "user" key to the DTSH.
- The Unit unlocks and then relocks.
- A special passage mode is possible by presenting the user key to the DTSH FOR A LONG PERIOD OF TIME. The unit will beep a second time and the LED will stay green.
- To deactivate passage mode, present any user key to the DTSH. The LED will change to red and the unit will go back to sleep.