
Mounting Instructions



Sliding Door Fittings Tritec Planning


for wood doors (max. 1 3/4" thickness)




Complete-sets

Set Tritec Art. No.	A inch	B inch	C Each	D inch	E max. inch	F inch	G inch	H max. inch (H=E-F+1")
941.07.045	70 7/8"	30 5/16"	3	29 1/2" - 35 7/16"	98 7/16"	1/4" - 3/8"	2 3/8"	99 1/8"
941.07.046	82 11/16"	24 1/8"	4	35 13/16" - 39 3/8"	98 7/16"	1/4" - 3/8"	2 3/8"	99 1/8"
941.07.047	90 9/16"	26 3/4"	4	39 3/4" - 44 1/16"	98 7/16"	1/4" - 3/8"	2 3/8"	99 1/8"
941.07.048	100"	29 15/16"	4	44 1/2" - 49 3/16"	98 7/16"	1/4" - 3/8"	2 3/8"	99 1/8"

Manufacturing dimensions (special model)									kg _i			
incl	hes	Each		inches H						Each		1
A	В	С	D	D1	E max. 98 7/16"	F 1/4" - 3/8"	G	max. 99 1/8" (H = E - F + Y)	capacity of the guide rail J	L	M	N
							(2 3/8")			1	2	2



Calculation for guide-rail length A for 1 door




Overhang Z + Passage width D + Door width D_1 - Door handle clearance X = Guide-rail length A




Make door handle clearance so that fingers do not get pinched when the door is manipulated! See page 5.

	Manufacturing dimensions (special model)														
	inches Each				inches					Kg H Load-bearing			Each		
A	B1	B2	С	D	D1	D2	max. 98 7/16"	1/4" - 3/8"	G	max. 99 1/8" (H = E - F + Y)	capacity of the guide rail J	к	L	М	N
									(2 3/8")			1	2	4	4



Calculation for total guide-rail length A for 2 doors




Door width D1 - Door handle clearance X + Passage width D + Door width D2 - Door handle clearance X = Total guide-rail length A




Make door handle clearance so that fingers do not get pinched when the door is manipulated! See page 5.

Standard installation



Installation with baseboards and trim



* Compensation disks 1/16", 3/16" and 3/8" To compensate for wall unevenness, order separately.

(Only 1 piece per wall fixture!)

	ArtNo.	inches
1221	941.07.105	1/16"
2	941.07.106	3/16"
	941.07.107	3/8"

** Spacers order separately.

ArtNo.	
941.07.104	

